



Parts List		Contents of Bolt Pack # 61310/B		Tools Required
1	Mainbody Drivers Side	8	CT Specialty J Bolt - black	3/4" Socket or Wrench 100 FT/LB Torque Wrench
1	Mainbody Passenger Side	2	Hex Bolt 1/2 x 1, Grade 5, UNC, Plated	
2	Tube Chains 12"	8	Flatwasher 1/2	
1	Bolt Pack	10	Lockwasher 1/2	
1	Instructions T61000 Series	10	Hex Nut 1/2, Grade 5, UNC, Plated	
		1	# 91310 2-Holed Spacer for Driver Side MB	
Shipping Weight	33.4 lbs 15.2 kg	2	Quick Pin Round 3/8 x 2-1/4	Clamp-On Application

- 1) Find best location to place the passenger side mainbody where the J-Bolts are able to hook onto the frame and fasten loosely for time being.
- 2) On driver's side, slip Brake Line through opening in mainbody and place J-Bolts into place on truck frame, fasten loosely for time being. Close space on driver's side mainbody with 2-holed spacer (#91310) and use hex bolts, lockwashers and hex nuts to fasten.
- 3) Tighten all mounting fasteners to the correct torque specifications listed below.

Bolt Size	Grade 5 Torque	Metric	Grade 8.8 Torque
3/8	30 Ft. Lb	8 mm	18 Ft. Lb.
7/16	54 Ft. Lb	10 mm	36 Ft. Lb.
1/2	72 Ft. Lb.	12 mm	75 Ft. Lb.
5/8	150 Ft. Lb	14 mm	103 Ft. Lb.
3/4	245 Ft. Lb	Maximum torque for weld or weld nuts is 38 FT/Lb	

Warning: Check Fasteners annually or before usage, if the Tiedown is damaged replacement may be necessary.

DO NOT drill or alter this product. This product is only intended for the application listed above.

See vehicle owner's manual for maximum Camper capacity (GVWR). This product is intended for usage with the correct towing accessories and not to be used with tow ropes, cables, chains or any type of stretch or elastic rope.

DSP Hitches are manufactured by 2114391 Alberta Ltd., Edmonton, Alberta, Canada

For more information on DSP and DSP products call 1-800-265-3377 or visit us at www.dsphitches.com